

# BOCCIA®

## TITANIUM

### CHRONOGRAPH CAL. OS 11 INSTRUCTIONS

#### ANALOG QUARTZ CAL. OS 11

#### FUNCTION

**FEATURES:** This chronograph is a multi-display-watch featuring a stopwatch function and a calendar.


Chronograph  
1/1 sec. basis  
(up to 59 min., 59 sec.)  
Calendar

**BATTERY LIFE:** Approx. 2 years  
(60 minutes chronograph operation per day)

**BATTERY REPLACEMENT:** As the battery in your watch is a monitor battery inserted at the factory, its actual life once in your possession may be less than the specified period. If the battery runs down, be sure to remove it as soon as possible. Do not leave the old battery inside the watch.

**BATTERY TYPE:** RW 399/SR 927


**ACCURACY:** +/- 20 sec./month  
(worn under normal circumstance)



\* Date correction cannot be effected between 21.00 h and 1.00 h

## INSTRUCTION MANUAL

- A. Operating chronograph**  
Button A: Start/Stop  
Button B: Reset



- B. Chronograph zero reset**
1. Pull crown to second click position
  2. Push button A to set chrono second hand to 12:00 (zero) position
  3. Return crown to normal position
  4. Push button B to check zero reset

Watches using these instructions: **3752-xx**, **3777-xx** (any Boccia id./configurator watch with chronograph function)